


# Instructions for setting up ICT App to control Protege Alarm, Access control

Download the ICT Protege GX Mobile App from the App store or Google Play. (Not to be confused with Protege Keypad app)




After launching the app, click on 'Create new Account'





Please enter your email as User Name and a password then hit 'save'.

After registration you will get a 'successfully registered' message.





Go back and log in with the details you just created.


Click don't allow for notifications. You will be then prompted to enter a PIN. This PIN is used for security App log in and to alter settings a later date – make it something to remember




Click on the drop down menu (as bellow screen shot defaulted to Never) and select how often you would like to be prompted to enter the PIN. If selecting Never please ensure your phones security settings prohibit un-authorized access into your phone. Select Always for highest security setting.



fter you have logged in you will be displayed a short instructional list. Click 'Got it' to be taken to the main pages menu.



Then click on My Places.



Click on my places to add a new site.


Name = Site Name

External address = <https://manage.visium.com.au>

Internal address = <https://manage.visium.com.au>

User name = firstname.lastname (Same as the <https://manage.visium.com.au> website username)

Password = (Same as the <https://manage.visium.com.au> website password)



< Add Place

🏠 Name

☁ External Address

☁ Internal Address

👤 Username

🔒 Password

Push Notifications

Save

After the app connects to the Visium cloud you are good to go. The My places menu briefs you on the controls. This is where you can open doors, arm/disarm areas, view the status of sensors or zones.

**IMPORTANT NOTE:** Clicking and holding on a door with unlock latch the door. Only to be used where you want to leave a gate / door permanently unlocked.



Click to access the Menu



Doors: Tap to Lock/Unlock, Long Press to Latch Unlock



Areas: Tap to Arm/Disarm, Long Press to Force Arm (if allowed)



Sensors: Tap to Bypass/Remove Bypass, Long Press to Latch Bypass (if Allowed)



Controls: Tap to Turn On/Off, Long Press to select Activation Time

× GOT IT

Integration

24HRENABLED - ARMED

Trouble

24HRENABLED - ARMED

Click on the tabs or swipe left/right to switch between pages



Home



Doors



Areas






Sensors



Controls





-  **Trouble**  
24HREENABLED - ARMED
-  **Integration**  
24HREENABLED - ARMED
-  **shed**  
24HREENABLED - DISARMED